


**Digital Hand-Tachometer**  
**Tachymètre Numérique Portatif**  
**Tachómetro digital manual**  
**Tachimetro digitale a mano**

N0000.930 A



MODE

▶ rpm ▶ **m/min** ▶ m/sec ▶ ft/min ▶ ft/sec ▶ in/min ▶ m ▶ ft ▶ in ▶



m/min **0.10 – 1999**

ft/min **0.40 – 6550**

in/min **4.00 – 78700**


m/sec **0.10 – 33.3**

ft/sec **0.10 – 109**

m **0.00 – 99999**

ft **0.00 – 99999**

in **0.00 – 99999**



A

click

B

C

setting U = 0,1 m